

If all cables come into the wiring centre, then relays 1 and 2 can be combined - using S2 and O2 to control the boiler.

ent