




- Input 1 - Gate leaf stop
- Input 3 - Opens the gate leaf.
- Input 3P - Opens the gate leaf for pedestrian access
- Input 4 - Closes the gate leaf.
- Input 7 - Opens and closes the gate leaf. The gate leaf inverts its direction of motion or stops, depending on the chosen selection made on the dip-switches (see selecting functions of the manual)

Title Fibaro Relays For CAME BK-1200 Gate Control		
Author Arron Gilder Fibaro UK		
File Fibaro Relays For CAME BK-1200 Gate Control.dsn		Document
Revision 1.0	Date 22/10/2015	Sheets 1 of 1